

No Suds

Product # 774

Glass cleaner for automatic brushes

This low-foaming liquid detergent removes stubborn mineral film and water spots from glassware cleaned with automatic electric brushes. It's oil-free formula powers away tough residues and water spots to ensure glasses are clean enough to maintain the true flavor and aroma of beverages.

Removes:

- Beverage residues
- Grease
- Water spots
- Lipstick
- Oils
- Stubborn lime film

Features and Benefits

- Low-foaming liquid cleaner is designed for electric brush washers.
- Removes grease, oils, lime film, water spots and other unsightly residue from glassware.

Properties

Appearance.....	Gold liquid
Fragrance.....	Detergent
Specific gravity.....	1.11
pH.....	1.50-2.00
Foaming.....	Low Foam
Application.....	Use with electric brushes

Directions Complete directions on product label

For washing with electric brushes, use one capful (3/8 ounce) to 3 gallons of water. (Three strokes of quart dispenser provides 3/8 ounce) rinse glasses with clear water.

Active Ingredients

Water
Citric Acid
Dye

CAS Number


7732-18-5
77-92-9
Proprietary

Safety

Caution: Keep out of the reach of children.

DOT Shipping (ground transportation)

Proper Shipping Name:	None
Class:	None
ID Number:	None
Packing Group:	None



Quantities

30, 3500 & 55 gallon
5 or 6 gallon
6 X 1 gallon
4 X 1 gallon
12 quarts/case



Milwaukee, WI 53224 • 1-800-743-6417 • Fax 414-354-9219 • www.athea.com